Smart Home Wi-Fi IP Camera













Quick Installation Guide

Quick Guide for APP Installation

App Installation: 1.

For iOS users: a)

- Scan the QR code (on cover page of the quick guide) for iOS system to download and (1) install the APP "Yoosee" with your iPhone/iPad;
- Search "Yoosee" in App Store, download and install; (2)
- Input "www.yoosee.co" on PC browser for iOS QR code, download and install the APP. 3

For Android users: b)

- Scan the QR code (on cover page of the quick guide) for Android system to download and (1) install the App "Yoosee" with your Android device;
- Search "Yoosee" in Google Play, download and install;
- Input "www.yoosee.co" on PC browser for Android system QR code, download and install (3) the APP

Account Registration & Login: 2.

- Open "Yoosee" APP and register for an account for new user,
- Click "Register" on Login page, input your mobile phone number or Email to register and set 1 2 password as the prompted by APP interface.
- Login with registered account to start pairing or viewing of camera device. Currently WeChat and Line account can be used for login to "YooSee" APP 3

Adding a New Device: 3.

Power the camera device and follow the APP prompts to start pairing the camera device when beeping sound is heard from the camera. (If beeping sound is not heard from the camera after sometime, please press and hold the reset button for the camera device until you get a prompt tone / voice prompt, this will activate the camera device reboot to default settings. Start pairing after the camera device is restored to factory settings.

2) Add with Ethernet connection:

- Power the camera device, connect the ethernet cable from router to RJ45 port of the camera device with an ethernet cable, the indicator light for network will be lited;
- Start "Yoosee" APP, click the"+"button on the top right corner of the device list, select "Add new device" and then "Wired connection". Click "Next" on "Prepare the device" page then click the ID number of the camera on "New device list" page to add;
- ③ Create a device name and input the password (Default password: 123) to complete adding procedures

Connect by AP Standalone Mode: (Applicable to environment without network)

- ① Power camera device, wait for camera to launch a hotspot in mobile WLAN interface (generally "GW_AP_XXX", the "XXX" here refers to the ID number of the camera), select the hotspot to connect;
- ② Open "Yoosee" APP, select and click "skip, shift to AP mode" on "Configure network" page and select "Confirm" in pop-up window to enter Standalone Mode.



4. Add online device: Manual Operation:

Start "Yoosee" APP, click the "+" button on the top right corner or center of interface choose "Add online device" of "All devices", select "Add online device", input device ID and password, create a device name, click "Save" on the top right corner of the page to complete camera device adding procedures.

5. Understanding YooSee APP:





- Camera Device View: Click to view camera device;
- 2. Device Status: Camera device status (Online / Offline);
- 3. Rename Camera Device: Customize, rename the camera device;
- 4. Device sharing: Click to share camera device, QR code or link to add camera device;
- 5. Defense: Arm / Disarm security features for camera device
- 6. Playback: Playback recorded video for camera device (Micro SD Card must be available)
- 7. Settings: Camera device management settings;
- 8. Device: Camera device information interface;
- 9. Message: Alarm notification log
- Image: Snap shots for camera device;
- 11. My: Account information & details
- 12. Camera Settings: Management & settings to camera device
- 13. Preset View: Setting preset view position and selecting preset position view.
- * If camera device has RF 64 zones features, RF security components can be paired to each preset view position. Only certain models contains preset view features.
- 14. Connection Speed: Camera device connection bandwidth
- 15. Number of Audience: Display number of user viewing camera device
- 16: Current Time: Display current date and time
- 17. Resolution: Switch between HD, SD or LD resolution during view
- 18. Switch View: Switch view to large screen
- 19. Recording: Recording of current view video
- 20. Intercom: Press and hold to speak.
- 21. Snapshot: Click to snapshot current image
- 22. Audio: Click to open or close camera device background audio.


6. Settings:



- 1. Device Information: Details & information for camera device
- 2. Time Settings: Set date and time to camera device
- 3. Picture & sound: Set picture resolution and sound adjustment to camera device
- 4. Security settings: Set Time to arm & disarm camera device. * Only for certain models
- 5. Defense Settings: Set time to arm and disarm camera device
- 6. Network Settings: Switch Wifi connection or to camera device standalone mode.
- 7. Alarm Settings: Alarm notification & Buzzer, Motion Detection & Sensitivity adjustment
- 8. Record Settings: Display Micro SD card capacity and recording options
- Add sensor: Add common security sensors (Door/Window sensor, PIR), Remote control
 and Special sensors (Smoker detector sensor, Gas detector sensor). *Only for certain
 models.
- 10. Firmware update: Update latest firmware for camera device
- 11. Unbind devices: Unbind device from APP account

7. Sharing Camera Device:









Start "Yoosee" APP; click the blue icon button on the top right corner at device main interface. APP proceeds to next interface, user for YooSee APP can scan QR code to add camera device. Alternatively, click the "copy" button and send to user whom you wish to share camera device. Administrator for camera device can delete users by clicking the blue icon button at device main interface

Method 1: Account sharing. Enter mobile phone number or email address to friends or relatives who have registered for YooSee APP account. Click the search button on the right to confirm that the account exists; click "Share" and confirm. Upon receiving the invitation notice, click on confirm and accept the shared device.

Method 2: Share with Device to Device. Click "Face to Face Sharing" in the lower left corner of "Share Management" to display the QR code. Let your friends or relatives scan the QR code to add the camera device you wish to share.

Click "Scan" in the upper left corner of "Device List" to scan the QR code.

*Camera device will only recongized one Administrator (First user pairing camera) thus if camera device is paired, other users can only add camera device via sharing. To conduct re-pairing to camera device, administrator must unbind camera via APP or reset camera to factory settings.

Quick Guide for PC Client Installation


CMS Client Downloads:

Visit "www.yoosee.co" on computer browser, click "CMS" to download the software to computer or laptop.



2. CMS Client account and login:


Open CMS software (Default user name: "admin", no passwordrequired) or Yoosee APP account and click OK to login.




3. Add Device:

After successful login, the software will automatically search devices in LAN. A dialog box will pop-up if any device is found, click "Add all", devices will be added into the list.

Manually adding: Click the "+" on the left interface, select the "Manual add device", input device name, ID and password and click OK to complete adding.





4. Monitoring:

Open CMS software, right-click on Device List and select "all connect" option in the menu; or select an added device in Device List and right-click and select "Start monitoring" in pop-up menu.





5. Frequently asked questions

① Device is offline is promoted in the device list

A: Please check if the camera properly connected to the network, check whether the indicator light is always on. Please check if router normal.

What should you do when the APP of mobile phone cannot receive the push notification.

A: Check whether alarm and alarm push notification are turned on in

the alarm setting and confirm to set "Defense" .

Meanwhile check

the Android phone background progress whether it's forbidden by system or anti-virus software.

3 How to do with motion detection false alarm.

A: Update firmware version (above 14.0.0.76) and APP (above 00.46.00.13), adjust the sensitivity in the setting of the device; Also can adjust through configuration file by changing: md_level = 3 (1~6, smaller numbers more sensitive).

Failed to search video file when playing video.

A: Please check if SD card damaged; please check the search time of the video file, and check the system time of the camera.

The camera cannot connect to WiFi.

A: Please check whether the password of WIFI is correct.

Ensure the WiFi is 2.4G cause the device does

not support 5G network.

The router does not limit WiFi access such as AP isolation,

anti-freeloading and so on.

Some phones need to provide targeting rights and turn on targeting to get a list of WiFi.

6 Cannot find the AP device in the WiFi list of the mobile phone.

A: The firmware version does not support.

Mobile phone and device are too far away.